











# ATTACHING ACCESSORIES - I



NOTE

Be careful when using tools !

Make sure the tank functions correctly before installing the accessories.



### TRACK TENSION ADJUSTMENT

- 1 Unscrew and take off wheel shown with Allen key.
- 2 Unscrew track adjuster as illustrated.
- 3 Turning the track adjuster clockwise will increase the track tension.
- 4 Turning the track adjuster counterclockwise will decrease the track tension.